



SINGLE conference room


1 Setting up a single conference room



2 Starting a teleconference




3 Ending a teleconference in a single conference room




MULTIPLE conference room

1 Setting up a multiple conference room



2 Starting a teleconference



3 Ending a teleconference in a multiple conference room

